

LED Accessories

REVOLUTION LR-157™ LOAD RESISTOR

2 Per Pack

This kit comes complete with 2 (two) 50 Watt 6Ω Load Resistors & 4 (four) wire connectors.



PRODUCT NAME	Revolution LR-157™
Sku Number	834760041023

Important

Not all vehicles require a load resistor for the "Turn Signal Circuit".

Please test your vehicle prior to purchasing these resistors. To perform a self test, simply install your new LED bulb into your socket. Next activate your signal. If your LED bulb does not blink, or if it blinks rapidly, than you must install a load resistor. If your indicator light blinks as normal, than no load resistor is needed. Also, you may need to install more than one load resistor per circuit, depending on how many lights are wired to that circuit. To determine if you need more than one load resistor, please initiate self-test above after installing the LED bulb and load resistor.

